	1200 9 7 4000
1. CASE NO. G 9230065 2. INVESTIGATOR'S ID 3. OFFICE CODE	EPIDEMIOLOGIC
(103/00001011	INVESTIGATION
4. DATE OF ACCIDENT 9 2 0 2 1 0 5. DATE INVESTIGATION INITIATED 9 2 0 4 0 7	REPORT
6. SYNOPSIS OF ACCIDENT OR COMPLAINT After making toast in the kit	chen with the
toaster oven the toaster oven was turned off, bu	it stayed on, oven
over heated and began smoking. There was no fir	e or damage to the
house. The unit was unplugged with only minor d	liscoloration above
the control panel.	
7. LOCATION (Hame, school, etc.) 8. CITY	9. STATE
Home 1 0 Madison	. WI 555
10A FIRST PRODUCT 11A. TRADE/BRAND NAME, MCCEL NUMBER. MANUFACTURER & ADDRESS Bla	ack & Decker Model No.
Toaster-oven 0216 TRO-500 TYI, Shel	
108. SECOND PRODUCT 118. TRADE/BRAND NAME, MODEL NUMBER, MANUFACTURER & ADDRESS	
None 0000	
12. AGE OF VICTIM 13. SEX (Use numerical code) 14. DISPOSITION MALE -1 FEMALE -2 UNKNOWN -3 14. DISPOSITION N / A NO injury 9	15. INDURY DIAGNOSIS No injury
18. 900Y PART N/A 17. RESPONDENT(S) (Mother, Frend) Both husband and wife users 18. TYPE :NVI ON SITE ITELEPHOI OTHER	,
21. CASE SOURCE 22. REVIEWED BY Multi 9 Consumer 0 7 892	YR MO DAY 920521
23. PERMISSION TO DISCLOSE NAMES	
(NON-NEISS CASES ONLY) CPSC MAY DISCLOSE MY NAME X CPS	C MAY NOT DISCLOSE MY NAME
24. NARRATIVE (See Instructions on Other Side)	ICE DIRECTOR REVIEW DATE
NOTE 7 17 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	
With the second	
d d	
(USE OTHER SIDE AND ADDITIONAL SHEFTS IF NECESSARY)	
THE REPORT OF THE PARTY OF THE	

THROUGH 5/31/94 OMB NO. 3041-0029



Line #24, Narrative

Pre- Accident: I spoke with the husband on 4-28-92 and the wife on 4-7-92, on separate occasions. There accounts are basically the same. At the time of its overheating, the toaster oven had only been used for a two week period as it had just been They had two weeks of experience operating this purchased new. toaster over without any problem noted. They had looked over the instruction manual which is attached to this report. The of the short period of use the unit not been cleaned. They reported there was no build-up or crumb or grease. The unit was located sitting on the kitchen counter about 12 inches from the refrigerator. There is a under the counter mount for this unit, which fortunately had not been installed. No extension cord was used. A radio may have been plugged into the other half of the outlet. There were no children involved in this incident, only two well rested adults. Prior to the incident, they had just toasted two rolls and left the kitchen to eat in another room.

The home was built by the respondents approximately 17 years ago. The home has copper electrical wiring and does not have GFI circuits in the kitchen.

Accident: The husband and wife smelled something burning and went to the kitchen to investigate. They saw smoke coming from the control panel of the toaster oven and the heating elements glowing red hot. The top of the oven face above the control panel was discolored from the heat or smoke (see photo page one). They heard no electrical or cracking sounds. They oven was unplugged. No fire occurred.

Post- Accident: No one was injured and there was no damage to the kitchen. No fuses tripped in the home's circuitry. The matter was reported to the Consumer Protection Bureau of the DATCP. Several weeks later the unit was returned to Sam's for a full refund. Store Manager Al Roberts reports that he returned the unit to the manufacturer.

Product Identification: See attached Photos on pages 1, 4 and 5 of photo section. Also see attached instruction book. The bottom photo on page 1 shows where the model numbers are stamped into the sheet metal bottom of oven. The following was copied from the bottom of the unit: "Black & Decker Model No TRO-500 TY1 Shelton, CONN. 120 Volts- 1500 Watts, 50-60 Hz- AC ONLY, Household use only, UL Toaster Listed 228 E"

The product is constructed of metal on all surfaces, except for the white color end panels(see photos on pages 2 and 3) which are made of a type of plastic. The control knobs and parts of the control panel are also plastic. Page Two CPSC No 182 Item 24

Operational safeguards are listed on page 2 and 3 of the operators manual. There is a signal light on the control panel to show when the unit is on.

Comments: There are two possibilities that could explain what occurred in the above overheating situation. First, the user when making toast, could have been somewhat unfamiliar with use of the identical top and bottom knobs. The top knob turns on the oven and controls its temperature, and the lower identical knob controls the cycling time of the toaster for light or dark toast. If the user put the bread in the toaster oven, closed the oven door, pushed down the toaster lever, and then turned the top knob to the right, mistakenly for dark toast (this would result in the oven control being put on- see photo on page one). While the toaster is operating, the unit would ignore that the oven control The door would pop open when the toast is ready. As long as the toaster is left with the door open, the heating element is off. However, if the door is now closed with the top oven knob still to the right, then the oven will automatically start. called the Black & Decker service repair center in Wauwatosa, WI and spoke to Jeff Johnson (414-453-4240), a technician who said her was familiar with this product. He said that the oven control knob does not shut itself off when the toaster is operated. Also, he stated that the oven will heat indefinitely and get very hot, especially with nothing in it to bake, since the unit has no fusible link to shut it off if it reaches a certain temperature. I reviewed the above scenario with him and he thought this was possible, or even likely.

Second, it is possible that the toaster switch stuck and failed to release when the oven door popped open. The users did not report that the elements stayed on when the door opened to remove the rolls.

Either of the above scenarios could be avoided through produce redesign as follows: require a heat sensitive fuse link to shut the oven off when a target temperature is reached in the control panel. The first scenario could be avoided by using a spring loaded oven switch which would turn off when ever the toaster level is moved on or off (or whenever the door opens).

Attachments:

- 1. Photos of the unit taken at the retailer where the unit continues to be sold.
- 2. A copy of the owner's "Use and Care Book"
- 3. Release of name form.

902 Ann Street Madison, WI 53713 20 7 23 ဖ 6 a. DESCRIPTION OF PRODUCT(S) 26 29 NAME OF COMPLAINANT STREET ADDRESS BRAND NAME GIVE DETAILS OF COMPLAINT, INJURY, OR ILLNESS. DESCRIBE HOW INCIDENT OCCURRED. USE REVERSE SIDE MANUFACTURER, IMPORTER OR DISTRIBUTOR NAME AND ADDRESS SERIAL NO PRODUCT DAMAGED BEFORE INCIDENT YES C. NO [] HOW PRODUCT ACQUIRED MEDICAL TREATMENT RECEIVED TYPE OF INJURY OR ILLNESS BURN D FRACTURE D VICTIM'S AGE PHYSICIAN'S OFFICE SOURCE OF REPORT **中半に**る FOLLOW-UP ACTION RECEIVING OFFICE いおかにすると BLACK 04871 6 ARASTACES 出いるのでして NO X という ひいとばい 1045750 とおかと B 1 ひととい ないのからのような STOKE PT G かりれな のなかと **CONSUMER PRODUCT COMPLAINT REPORT** 子もコスタス は用い入か エカヤの VISIT EMERGENCY ROOM O OTHER HOSPITAL OTHER O SPECIFY 27. 21 06484-4797 700 SECOND HAND 10957175 IF INJURY OR ILLNESS COMPLETE ITEMS 20 - 24 8 かかいけっとる DATE RECEIVED VICTIM'S SEX
MALE □ FEMALE □ Jugo アとせ YES [] のないころの CUT II PRODUCT REPAIRED
BEFORE → INCIDENT ←
YES □ NO 🗗 YE 4×1400 ロメウム OTHER D 0 P FROM FOR COMMISSION USE ONLY WARNING LABEL (>++&c~~ 2)16 YES \$ y 后早 OYEN. Sans SPECIFY としない J DIESOLO OTHER [] g Th NO II OTHER [] なっていまれる、 - DISCONSECTED ノンはおけん 12 6 28. RECEIVED BY 2. TELEPHONE NO. 608-845-3949 œ (IE, MOVED compacise by FCD VA, W153 YES [077). BODY PART(S) INVOLVED LOT/BATCH NO. MODEL/STYLE NO DEALER NAME AND ADDRESS ر ا ا TRA SPECIFY - AFTER 70 70 SAM'V 3キツンOC ~~ SHULL SIP CODE 6b. Date Aquired カラナル SPECIFY NO X 12 YESTI GATED くのみて よっと 500 21/92 ハリスめ CONTROL A TO STER ングキナーシャ けるまいから 2007 YESY INSTRUCTIONS 19 なけらうとうとと 28 30 AGE OF PRODUCT (ESTIMATE IF NECESSARY) terson -PRODUCT CODE(S) DOCUMENT NO 573 2 22 5 NO O ルワ 9 CONTROL ARCOA タンタ X 完 なとせ L と こくたと INCIDENT N かななら

DISTRIBUTION

ENDORSER'S NAME AND

(REV. 1/78)

Wis. Dept. of Agriculture,

Consumer Protection

Consumer Protection Div.

MAY -	5	1997
-------	---	------

U.S.	CONSUMER	PRODUCT	SAFETY	COMMISSION
------	----------	---------	--------	------------


AUTHORIZATION FOR RELEASE OF NAME

Thank you for assisting us in collecting information on a potential product safety problem. The Consumer Product Safety Commission depends on concerned people to share product safety information with us. We maintain a record of this information, and use it to assist us in identifying and resolving product safety problems.


We routinely forward this information to manufacturers and private labelers to inform them of the involvement of their product in an accident situation. We also give the information to others requesting information about specific products. Manufacturers need the individual's name so that they can obtain additional information on the product or accident situation.

Would you please indicate on the bottom of this page whether you will allow us to disclose your name. If you request that your name remain confidential, we will of course, honor that request. After you have indicated your preference, please sign your name and date the document on the lines provided.

	You are hereby authorized to disclusion with the information collected on	ose my name and address this case.
11	My identity is to remain confident	ial.
/Sign	ature)	5//92 (Date)




Chaze - up of




better

thousehold use Only (9) Toaster Listed 2. AC ONLY No INC. Black & Decker Mode


Se Se




Front views of Black a Dector Toast - R-Ove TRO 500





width of glass door



Width of Face is 14/2' by 7/2" heigh







right sic

back

Sides en sient sides et vient

3

Back of Box

IUast-U-n-national Broiler



Our Heat Guard Mounting Hood lets ye save space by mounting the TROSC under your cabinet (sold separately)

Perfect Complement to a
Microwave Oven


Leas Our Ay— Real or
Mas and Sales

Side of Box




Front of Box







·Toast-R-Oven™ ·Broilers



Model TRO510

Models TRO51/TRO68/TRO400-TRO600

1500 Watts, 120 Volts, 50/60 Hz. AC Only FOR HOUSEHOLD USE ONLY Listed by Underwriters Laboratories Inc.

SAVE THIS USE & CARE BOOK